

03-09 Dodge Ram Rear Bumper Installation Instructions

1. Tools Needed to Put New Bumper On: 9/16 Wrench, $\frac{3}{4}$ Wrench, $\frac{3}{4}$ Socket, 15 mm Socket, 21 mm socket.
2. Remove Stock Bumper. (3) 15mm bolts per side. (2) 15 mm bolts behind the license plate. (1) 21 mm bolt on each side.
3. Install Tie In Brackets Re-Using Stock Bolts. **Image A-1**
4. Snug tie in brackets, but do not tighten completely to allow for adjustment of the bumper to suit your liking.
5. Start 4 bolts connecting bumper to tie in brackets, but do not tighten all the way. Tie in brackets positioned on the outside, bumper brackets on inside.
6. Use provided $\frac{3}{8}$ x1 Bolts to attach top of bumper with top of frame. But also do not tighten completely. **Image A-2 & A-3**
7. Once all bolts are snug, move bumper to position of your liking, tighten bolts.



Image A-1 (Blue=21 mm, Red=15mm)



Image A-2



Image A-3

IF YOU HAVE ANY OTHER QUESTIONS. PLEASE EMAIL
affordableoffroadfab@gmail.com

Thank you

-Affordable Offroad Team