

1. Open hatch pull 3-10 mm bolts out of tail lights.
2. Cut bulbs off the wire close to bulb as possible.
3. Pull both inside panel's off along with the rear center bottom panel.
4. Disconnect the plug on the driver side.
5. Plug in new wire box and follow wire diagram to install new lights.
6. After all lights are connected and all lights are in working order put back together and enjoy.

Wiring

<u>Vehicle</u>	→	<u>Converter</u>
White/Orange	→	Red
Green/Red	→	Green
Brown	→	Brown
(2) Black	→	White

Reverse Light Wired Separate

<u>Vehicle</u>	→	<u>Light</u>
Brown/Green	→	White
Black	→	Black