

JK 2-DOOR BOLT ON SLIDERS INSTALLATION INSTRUCTIONS

1. UNBOLT BOTH CENTER BODY MOUNT BOLTS
2. DRILL EXISTING HOLES ON PINCH SEAMS TO $\frac{3}{8}$ " (4 HOLES/SIDE)
3. BODY MOUNT PLATES HAVE (F) FOR FRONT AND R FOR REAR OF JEEP
4. PLACE FLAT 3/16 WASHERS (PROVIDED) ON TOP OF MOUNTS AND HOLD UP TO TIGHTEN BODY MOUNT BOLTS
5. BODY MOUNTS DO NOT TIGHTEN ALL THE WAY TO ALLOW FOR FLEXIBILITY
6. MOVE SLIDER TO ALIGN WITH HOLES IN PINCH SEAM. INSTALL REMAINING HARDWARE

IF YOU HAVE ANY OTHER QUESTIONS. PLEASE EMAIL
affordableoffroadfab@gmail.com

Thank you

-Affordable Offroad Team