

Read all instructions before cutting! Cut the stock bumper from the top corner of the fog light and go straight across to about an inch below the far corner in the wheel well, there is a bolt there you need to retain (it's under the fender flare, see second picture). The fender flare needs to be cut approximately an inch above the corner where the stock bumper ends (reference second Picture)

