

WJ FRONT INSTALL #2



FIG 4



MAKE SURE ALL BOLTS FIT FRAME
HOLES...THEY MAY NEED TO BE REAMED OUT..

PUT BUMPER TOGETHER & INSTALL