

WJ FRONT INSTALL

DRY FIT BEFORE PAINT OR POWDER COAT

-PULL PLASTIC FRONT BUMPER OFF

-WITH A CUT OFF WHEEL CUT TO
INSIDE OF FRAME

-DRY FIT CENTER SECTION

MAKE SURE ALL BOLTS FIT FRAME HOLES
THEY MAY NEED TO BE REAMED OUT

-PUT BUMPER TOGETHER & INSTALL