

Jeep Grand Cherokee(ZJ) Rear Upper Door Armor

****Please Dry Fit Before Paint/Powder Coat****

Preparation-

- 1) Start by locating the three Phillips head screws that secure the inner door panel in place
You Will Need:
 - Phillips head screwdriver
- 2) Remove the inner door panel
- 3) Unplug the window control panel and pull the door handle to remove the plastic cover that contains the door handle and the lock mechanism
- 4) Place the door armor on the door and mark where the holes are to be drilled
You Will Need:
 - Any type of permanent marker
- 5) Drill all marks completely through to 5/16"
You Will Need:
 - 5/16" twist drill bit
 - Any type of drill

Installation-

All installation steps are the same for both driver's and passenger side of the vehicle

- 1) Set the door armor in place making sure that all holes are aligned
- 2) Using the provided hardware, insert the bolts through the armor and the door and snug the bolts enough to hold the armor in place
You Will Need:
 - Assorted Allen keys
 - 5/16" wrench
- 3) Tighten all the bolts and nuts evenly once the armor is centered
You Will Need:
 - Assorted Allen keys
 - 5/16" wrench
- 4) Once all bolts are fully tightened, you may plug in the window controls and reinstall the inner door panel

Links and Other Media:

Affordable Offroad Main Page- <https://affordableoffroad.com/>

Affordable Offroad ZJ Main Page- <https://affordableoffroad.com/product-category/jeep-grand-cherokee-zj-93-98/>

Reference Pictures:



